

Hot Knife™

INSTRUCTIONS

Warning!

Be aware that this is a limited use tool.

1. To avoid overheating and damaging the tool, depress the trigger for 15 seconds, then release the trigger for 15 seconds. Continue this cycle for a maximum of 5 minutes. Then let the tool rest for 2½ minutes. Using the tool longer than 5 minutes will cause heat damage and is not covered by the warranty.

2. Do not use a screwdriver to tighten the blade screws. Finger Tighten only!



Proper Tool Performance

1. Use only in 110 volt receptacles.
2. Keep the tool and blades clean and in good condition
3. Remove damaged tools from service immediately.
4. Never attempt repairs yourself.
5. Avoid tying or holding the trigger back for extended periods of time. This will cause the tool to overheat resulting in premature failure.
6. Make sure you use the tool in a well ventilated area.
7. Avoid cutting anything that could emit toxic gas such as Urethane or PVC.
8. Limit extension cords to 100 feet or less. 12/3 gauge cord is recommended when extension cords are needed.
9. Use caution when removing a hot blade from the tool.
10. This appliance has a polarized plug. One blade is wider than the other. To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, turn the plug over and reinsert. If it still does not fit, contact a qualified electrician, Do not modify the plug in any way.



Blades included in Original Hot Knife Kit