

SCULPTURE SUPPLY CANADA



SILICONE DEUX ADHESIVE

Technical Bulletin

PREPARING SURFACES

Appliance Surface: Make sure appliance is clean, dry and free of debris.

Skin Surface: Thoroughly clean skin with either alcohol or Westmore Effects PrimeONE (for maximum adhesion). Allow to dry completely.

APPLYING ADHESIVE

- 1) Apply a thin layer of adhesive to the appliance.
- 2) Apply a thin layer of adhesive to the skin.
- 3) Attach appliance with gentle pressure.

DEUX Adhesive is specially formulated to not require thinner.

REMOVING APPLIANCE

Using Westmore Effects SilicONE Adhesive Remover work around the edge of the appliance advancing slowly until adhesive begins to soften and edge lifts. Continue working until appliance is completely free. Residual adhesive may be removed with a sponge or towel and additional remover.

WARNINGS

- * For external use only
- * DO NOT get in the eyes
- * If irritation occurs discontinue use
- * Heavy inhalation of vapors may cause drowsiness
- * Heavy inhalation of vapors could irritate nose and throat
- * Keep tightly sealed when not in use
- * Keep out of reach of children
- * Store below 80°F (27°C) and above 40°F (5°C)
- * If separation occurs warm to room temperature and shake



FLAMMABLE : KEEP AWAY FROM FIRE and FLAME