

TASK 16®

Tough 80A/30D Urethane Rubber (formerly Flex Urethane 100-184)



www.smooth-on.com

PRODUCT OVERVIEW

TASK® 16 is a low odor, fast-setting Shore 80A/30D industrial liquid rubber that offers very high tear strength, impact resistance and wear resistance. **TASK® 16 is phthalate free, mercury free and MOCA free.** Mixed one part A to two parts B by weight, **TASK® 16** pours easily. **Working time is 6 minutes** and **handling time is 90 minutes** at room temperature. Cured rubber has exceptional performance characteristics and dimensional stability. **TASK® 16** can be colored with SO-Strong® or Ignite® colorants.

TASK® 16 is suitable for making fast rubber mechanical parts, gaskets, wheels and pulleys, impact resistant props, and archival master models. It is also used to make fast, wear resistant rubber molds for casting concrete or concrete stamping pads. **TASK® 16** is also an excellent choice for rotocasting to create hollow semi-rigid pieces.

PROCESSING RECOMMENDATIONS

START BY PREPARING YOUR MODEL...

Preparation - These products have a limited shelf life and should be used as soon as possible. Materials should be stored and used at room temperature (73°F/23°C). This material is moisture sensitive, so relative humidity should be below 50%. Wear safety glasses, long sleeves and rubber gloves to minimize contamination risk. Good ventilation (room size) is necessary.

TECHNICAL OVERVIEW

Mix Ratio: 1A : 2B by weight (gram scale required)

Mixed Viscosity (cps): 1,400 (ASTM D-2393)

Specific Gravity (g/cc): 1.08 (ASTM D-1475)

Specific Volume (cu. in. /lb.): 25.64

Pot Life: 6 minutes (73°F/23°C) (ASTM D-2471)

Handling time: 90 minutes (73°F/23°C)

Full Cure: 24 hours (73°F/23°C)

Color: Light Yellow

Shore Hardness: 80A/30D (ASTM D-2240)

Tensile Strength (psi): 2264 (ASTM D-412)

100% Modulus (psi): 855 (ASTM D-412)

Elongation @ Break: 233% (ASTM D-412)

Die C Tear Strength (pli): 197 (ASTM D-624)

Shrinkage: .0025 in./in. (ASTM D-2566)

Dielectric Constant (1 MHz): 4.59 (ASTM D150-87)

Dissipation Factor (1 MHz): 0.064 (ASTM D150-87)

* All values measured after 7 days at 73°F/23°C

Some Materials Must Be Sealed - To prevent adhesion between the rubber and porous surfaces, a sealing agent must be applied. SuperSeal®, One Step® or Sonite Wax® (available from Smooth-On) are suitable for sealing porous surfaces. A high quality spray shellac (Bullseye Clear Shellac from Zinser) is suitable for sealing modeling clays that contain sulfur or moisture (water based).

In all cases, the sealing agent should be applied and allowed to completely dry prior to applying a release agent.

Non-Porous Surfaces - Metal, glass, hard plastics, sulfur free clays, etc. require only a release agent.

Applying A Release Agent - A release agent is necessary to facilitate demolding when casting into or over most surfaces. Use a release agent made specifically for mold making (Universal® Mold Release available from Smooth-On). A release agent should be applied onto all surfaces that will contact the rubber.

IMPORTANT: To ensure thorough coverage, lightly brush the release agent with a soft brush over all surfaces of the model. Follow with a light mist coating and let the release agent dry for 30 minutes.

Because no two applications are quite the same, a small test application to determine suitability for your project is recommended if performance of this material is in question.

MEASURING & MIXING...

Liquid urethanes are **moisture sensitive** and will absorb atmospheric moisture resulting in bubbles in the cured rubber. Mixing tools and containers should be clean and made of metal or plastic.

IMPORTANT: Shelf life of product is drastically reduced after opening. Immediately replacing the lids on containers after dispensing product will prolong the shelf life of the unused product. **XTEND-IT® Dry Gas Blanket** (available from Smooth-On) will prolong the shelf life of unused liquid urethane products.

Safety First!

The Material Safety Data Sheet (MSDS) for this or any Smooth-On product should be read prior to use and is available upon request from Smooth-On. All Smooth-On products are safe to use if directions are read and followed carefully.

Be careful

Part A is an MDI prepolymer. Vapors, which can be significant if material is heated or sprayed, cause lung damage and sensitization. Use only with adequate ventilation. Contact with skin and eyes may cause severe irritation. Flush eyes with water for 15 minutes and seek immediate medical attention. Remove from skin with waterless hand cleaner followed by soap and water. Prepolymers contain trace amounts of MDI which, if ingested, must be considered a potential carcinogen. Refer to MSDS.

Part B is irritating to the eyes and skin. If contaminated, flush eyes with water for 15 minutes and seek immediate medical attention. Remove from skin with soap and water. When mixing with Part A follow precautions for handling isocyanates.

Important: The information contained in this bulletin is considered accurate. However, no warranty is expressed or implied regarding the accuracy of the data, the results to be obtained from the use thereof, or that any such use will not infringe upon a patent. User shall determine the suitability of the product for the intended application and assume all risk and liability whatsoever in connection therewith.

IMPORTANT: Pre Mix the Part B before using every time.

Measuring - An accurate gram scale is required to measure out 1A:2B. Inaccurate measurement can result in rubber partially curing or not curing at all.

Hand Mixing - After weighing and dispensing the required amounts of Parts A and B into mixing container, mix thoroughly for at least 90 seconds making sure that you scrape the sides and bottom of the mixing container several times. Pour entire quantity into a new, clean mixing container and mix again as directed above.

Mechanical Mixing - drill mix using a Turbine mixer or equal for 60 seconds followed by careful hand mixing for 60 seconds as directed above. Then, pour entire quantity into a new, clean mixing container and repeat mixing procedure.

Be Aware - this material has a short pot life. Pot life at elevated temperatures will be even less. Do not delay between mixing and pouring.

Although this product is formulated to minimize air bubbles in the cured rubber, vacuum degassing will further reduce entrapped air. A pressure casting technique using a pressure chamber can yield totally bubble free castings. Contact Smooth-On or your distributor for information about vacuum degassing or pressure casting.

POURING, CURING & PERFORMANCE...

Pouring - For best results, pour your mixture in a single spot at the lowest point of the containment field. Let the rubber seek its level **A uniform flow will help minimize entrapped air.**

Curing - Allow the mold or casting to cure (at least 90 minutes) at room temperature (73°F/23°C) before demolding. Do not cure rubber in temperatures less than 65°F/18°C. Cure time can be reduced with mild heat or by adding Smooth-On "Kick-It" Cure Accelerator. This material will reach full cure in 24 hours at 73°F/23°C.

Post Curing - After rubber has cured at room temperature, heating the rubber to 150°F (65°C) for 4 to 8 hours will increase physical properties and performance.

If using this rubber as a mold material, a release agent should be applied to the mold before each casting. The type of release agent to use depends on the material being cast. Contact Smooth-On or your Smooth-On distributor for more information.

Performance & Storage - Fully cured rubber is tough, durable and will perform if properly used and stored. The physical life of the rubber depends on how you use it. Contact Smooth-On directly with questions about this material relative to your application.



Call Us Anytime With Questions About Your Application.

Toll-free: (800) 762-0744 Fax: (610) 252-6200

The new www.smooth-on.com is loaded with information about mold making, casting and more.